

PTV430: User Manual

21.8"

4.3" LCD Display
Portable Digital Television
PVT430

User Manual

Getting started

Settings - main menu

DTV - digital television

Picture settings:

Channel Settings:

Setup:

Sleep Timer: Choose a set time for the TV to power off.

Time Zone: Set the time zone you are in.

DST: Turn daylight savings time On or Off.

Time Format: Set the format of the clock. Choose between 12-hour or 24-hour formats.

Auto Sync: This synchronizes the time with the broadcasting station. This is not adjustable.

Clock: This synchronizes the date and time with the broadcasting station. This is not adjustable.

Picture mode: Choose between Personal / Standard / Dynamic / Soft.

Contrast / Brightness / Sharpness / Tint / Color: You can adjust any of these from 0-100.

Color mode: Choose between Personal / Normal / Warm / Cool.

Zoom mode: Choose between Normal or Wide viewing modes.

Audio settings:

Audio Language: Choose between English / Spanish / French (not available for all channels).

Balance: Adjust the audio from left to right.

Main Menu:

Menu Navigation:

Warning: There is no memory card in the TV or USB storage device attached to the TV then the Slideshow, Music, Video or Browse functions will not work.

Note: Compatible USB devices are memory sticks and USB mass storage devices (external hard drives).

Slideshow

You can use the TV as a slideshow picture frame with music playing (music is optional). You must have a memory card inserted and/or a USB storage device attached with picture and music files (optional), for the slideshow function to work.

- Supported picture file types are JPEG, GIF and BMP.
- Supported music file types are MP3 and WMA.
- Supported memory card type is Micro SD.

1. Insert a memory card into the card reader slot and/or attach a USB storage device to the mini USB jack on the TV (see "Getting started: Connecting to a USB device").

2. Press the **[Home]** button, the main menu appears.

3. Use the **< >** buttons to scroll to "Slideshow", then press the **[OK]** button to confirm. The Slideshow home screen will open showing your picture thumbnails.

4. Use the navigation buttons to select a starting point for the slideshow, then press the **[OK]** button to confirm.

5. Use the **< >** buttons to switch between different slideshow playback modes, then press the **[OK]** button to start the slideshow.

6. If there is music on the memory card, it will play in the background. You may adjust the volume at any time during the slideshow.

Slideshow playback menu

1. Skip to the previous picture
2. Skip to the next picture
3. Rotate current picture 90 degrees
4. Play or pause the slideshow
5. Adjust the volume (select then use the **[vol+]** or **[vol-]** buttons)
6. Adjust the brightness
7. Display picture information
8. Zoom the current picture

1. During the slideshow, press the **[OK]** button to open the slideshow playback menu.

2. Use the **< >** buttons to select from the different playback options, then press the **[OK]** button to confirm your choice.

3. To resume slideshow playback, select the "Play" option from the menu, then press the **[OK]** button to confirm.

Slideshow sub menu

Exit Picture Information Switch storage device

1. During the slideshow, press the **[menu]** button twice to open the slideshow sub menu.

2. To switch between the memory card and USB storage device, select the "Switch storage device" option, then press the **[OK]** button to confirm.

3. To exit the slideshow, select the "Exit" option, then press the **[OK]** button to confirm.

Videos

You can use the TV to watch videos stored on a memory card or USB storage device. You must have a memory card inserted and/or a USB storage device attached with video files for the video function to work.

- Supported video file types are MPEG, AVI and DAT.
- Supported memory card type is Micro SD.

1. Insert a memory card into the card reader slot and/or attach a USB storage device to the mini USB jack on the TV (see "Getting started: Connecting to a USB device").

2. Press the **[Home]** button, the main menu appears.

3. Use the **< >** buttons to scroll to "Videos", then press the **[OK]** button to confirm. The "Select Source" screen will open.

4. Use the **< >** buttons to select the storage device you would like to use (Micro SD or USB Device), then press the **[OK]** button to confirm.

5. Use the navigation buttons to select the video you would like to play or folder you would like to open and press the **[OK]** button to confirm.

6. If you selected a folder, use the navigation buttons to select a video you would like to play and press the **[OK]** button to confirm.

Video playback menu

While a video is playing, the video playback menu is displayed at the bottom of the screen:

1. Play or pause the current video
2. Stop the current video
3. Skip to the previous video
4. Skip to the next video
5. Rewind ten seconds
6. Fast forward ten seconds
7. Adjust the volume (select then use the **[vol+]** or **[vol-]** buttons)
8. Adjust the brightness
9. Switch the playback mode
10. Change the subtitle language (if applicable)
11. Audio mode
12. Full screen mode

1. Use the **< >** buttons at any time to choose from the video playback options, then press the **[OK]** button to confirm your choice.

2. To adjust the video volume, you must select the "Adjust Volume" option **[⏮]** from the playback menu, then use the **[vol+]** or **[vol-]** buttons to lower or raise the volume.

3. To stop playback and return to the video menu, press the **[menu]** button repeatedly until the main menu appears OR press the **[Home]** button.

4. To exit "Video" and return to the main menu, press the **[menu]** button repeatedly until the main menu appears OR press the **[Home]** button.

FM Radio

You can use the TV as a FM Digital Radio. You must have headphones plugged into the TV for the FM Radio function to work.

FM radio home screen

While listening to FM Radio, the following screen appears with the FM Radio function along with the bottom of the screen:

1. Skip backward to the next available radio station

2. Manual search backward on the radio frequency dial

3. Manual search forward on the radio frequency dial

4. Skip forward to the next available radio station

5. Adjust the volume (select then use the **[vol+]** or **[vol-]** buttons)

6. Save the current station to the "Favorite Channels" list

7. Scan and save all available stations the radio frequency will be listed in the right window where you can use the navigation buttons to select a station)

Music

You can use the TV as a music player. You must have a memory card inserted and/or a USB storage device attached (with music files) for the music function to work.

- Supported music file types are MP3 and WMA.
- Supported memory card type is Micro SD.

1. Insert a memory card into the card reader slot and/or attach a USB storage device to the mini USB jack on the TV (see "Getting started: Connecting to a USB device").

2. Press the **[Home]** button, the main menu appears.

3. Use the **< >** buttons to scroll to "Music", then press the **[OK]** button to confirm. The "Select Source" screen will open.

4. Use the navigation buttons to select the storage device you would like to use (Micro SD or USB Device) then press the **[OK]** button to confirm.

5. Use the **< >** buttons to scroll to the song you would like to play or folder you would like to open and press the **[OK]** button to confirm.

6. If you opened a folder, use the navigation buttons to select a song you would like to play and press the **[OK]** button to confirm.

Music playback menu

While music is playing, the music playback menu is displayed at the bottom of the screen:

1. Play or pause the music
2. Stop playing music and return to the play list
3. Play the previous track
4. Play the next track
5. Rewind ten seconds
6. Fast forward ten seconds
7. Adjust the volume (select then use the **[vol+]** or **[vol-]** buttons)
8. Display the playback information
9. Switch the playback mode

1. Use the **< >** buttons at any time to choose from the music playback options, then press the **[OK]** button to confirm your choice.

2. To adjust the music volume, you must select the "Adjust Volume" option **[⏮]** from the playback menu, then use the **[vol+]** or **[vol-]** buttons to lower or raise the volume.

3. To stop playing and return to the music menu, press the **[menu]** button any time or select "Stop" from the music playback menu.

4. To exit "Music" and return to the main menu, press the **[menu]** button repeatedly until the main menu appears OR press the **[Home]** button.

FM Radio

You can use the TV as a FM Digital Radio. You must have headphones plugged into the TV for the FM Radio function to work.

FM radio home screen

While listening to FM Radio, the following screen appears with the FM Radio function along with the bottom of the screen:

1. Skip backward to the next available radio station

2. Manual search backward on the radio frequency dial

3. Manual search forward on the radio frequency dial

4. Skip forward to the next available radio station

5. Adjust the volume (select then use the **[vol+]** or **[vol-]** buttons)

6. Save the current station to the "Favorite Channels" list

7. Scan and save all available stations the radio frequency will be listed in the right window where you can use the navigation buttons to select a station)

Browsing files

You can use the TV to browse music, video or picture files on your memory card or USB storage device.

1. Insert a memory card into the card reader slot and/or attach a USB storage device to the mini USB jack on the TV.

2. Press the **[Home]** button, the main menu appears.

3. Use the **< >** buttons to scroll to "Browse", then press the **[OK]** button to confirm. The "Browse" home screen will open where you can view all of your files.

4. To switch between the memory card and USB storage device at any time, press the **[menu]** button, then scroll to "Switch Storage Device", then press the **[OK]** button to confirm.

5. As you scroll through the files or folders, the name of the file or folder is displayed along the bottom left corner of the screen.

To browse video files

1. Open "Browse" from the main menu.

2. Use the navigation buttons to select a folder or video file and press the **[OK]** button to confirm. If you open a folder, then choose a video file within that folder to open.

3. The browser options are displayed on the screen. Use the **< >** buttons to select a browser option, then press the **[OK]** button to confirm your choice.

4. During playback, press the **[OK]** button to bring up the playback options.

5. To return to previous menu, press the **[menu]** button.

6. To exit to the main menu, press the **[Home]** button at any time.

To open picture files

1. Open "Browse" from the main menu.

2. Use the navigation buttons to select a folder or picture file, then press the **[OK]** button to confirm. If you open a folder, then choose a picture within that folder to open.

3. Press the **[OK]** button again to open the picture's browser menu:

4. To set a picture as the TV startup screen:

- a. Select a picture and press the **[OK]** button to open the picture's browser menu.
- b. Use the navigation buttons to select "Set Picture to startup screen", then press the **[OK]** button to confirm.
- c. The TV will ask you to confirm to set this picture as a logo. Use the navigation buttons to choose Yes or No, then press the **[OK]** button to confirm your choice.

5. To return to previous menu, press the **[menu]** button to open the browser menu, then select "Exit", then press the **[OK]** button to confirm.

6. To exit to the main menu, press the **[Home]** button at any time.

Safety precautions

WARNING

to prevent fire or shock hazard, do not use the plug with an extension cord, receptacle or other outlet unless the blades can be fully inserted to prevent blade exposure.

to reduce the risk of fire electric shock, do not expose this appliance to rain or moisture.

31.2"

FRONT

BACK